



Contents

01 - Self-diagnosis	1
1 General to self-diagnosis	1
1.1 General to self-diagnosis	1
1.2 Features of self-diagnosis	1
1.3 Technical data of self-diagnosis	1
1.4 Significance of EPC warning lamp (fault lamp for electronic accelerator) in dash panel insert	3
1.5 Significance of exhaust emissions warning lamp	3
1.6 Connecting fault reader V.A.G 1551 and selecting engine electronics control unit	4
1.7 Connecting vehicle diagnosis, testing and information system VAS 5051 and selecting engine control unit	7
2 Fault memory	9
2.1 Fault memory	9
2.2 Interrogating and erasing fault memory of engine control unit	10
2.3 Automatic test sequence	11
3 Fault table: from V.A.G code 16486 / SAE P0 codes	12
3.1 Fault table: from V.A.G code 16486 / SAE P0 codes	12
4 Fault table: from V.A.G code 17510 / SAE P1 codes	16
4.1 Fault table: from V.A.G code 17510 / SAE P1 codes	16
5 Final control diagnosis	26
5.1 Final control diagnosis	26
5.2 Performing final control diagnosis	26
6 Readiness code	31
6.1 Readiness code	31
6.2 Reading readiness code	32
6.3 Generating readiness code	32
7 Measured value blocks	37
7.1 Measured value blocks	37
7.2 Safety precautions	37
7.3 Read measured value block	37
8 Evaluating measured value blocks, display groups 0...6 -Basic functions	38
8.1 Evaluating measured value blocks, display groups 0...6 -Basic functions	38
9 Evaluating measured value blocks, display groups 10...29 -Ignition-	43
9.1 Evaluating measured value blocks, display groups 10...29 -Ignition-	43
10 Evaluating measured value blocks, display grps 30...49, 99 -Lambda regulation-	46
10.1 Evaluating measured value blocks, display grps 30...49, 99 -Lambda regulation-	46
11 Evaluating measured value blocks, display groups 50...69 -Speed regulation-	51
11.1 Evaluating measured value blocks, display groups 50...69 -Speed regulation-	51
12 Evaluating measured value blocks, display groups 70...75 -Exhaust gas recirculation-	54
12.1 Evaluating measured value blocks, display groups 70...75 -Exhaust gas recirculation-	54
13 Evaluating measured value blocks, display group 100 -Readiness code-	56
13.1 Evaluating measured value blocks, display group 100 -Readiness code-	56
14 Evaluating measured value blocks, display groups 120...129 -Communication-	56
14.1 Evaluating measured value blocks, display groups 120...129 -Communication-	56
24 - Mixture preparation, Injection	58
1 Servicing injection system	58
1.1 Servicing injection system	58
1.2 Fitting locations overview	58
1.3 General notes on injection	61
1.4 Removing and installing parts of the injection system	63
1.5 Dismantling and assembling intake manifold	74



1.6	Dismantling and assembling fuel rail with injectors	77
1.7	Dismantling and assembling air cleaner	80
1.8	Safety precautions	83
1.9	Rules for cleanliness	84
1.10	Technical data	85
2	Checking components	85
2.1	Checking components	85
2.2	Checking Lambda probe heating before catalyst	85
2.3	Checking Lambda probe heating for Lambda probe after catalyst	88
2.4	Checking throttle valve control part	90
2.5	Checking intake manifold pressure sender	92
2.6	Checking intake air temperature sender	96
2.7	Checking coolant temperature sender	100
2.8	Checking engine speed sender	104
2.9	Checking injectors	105
2.10	Checking fuel pressure regulator and holding pressure	112
2.11	Checking intake air system for leaks (unmetered air)	115
2.12	Checking intake air preheating	116
3	Checking functions	117
3.1	Checking functions	117
3.2	Idling check	117
3.3	Checking Lambda probe and Lambda regulation before catalyst	118
3.4	Checking Lambda probe and Lambda regulation after catalyst	122
3.5	Checking ageing of Lambda probe before catalyst	125
3.6	Checking engine operating mode	126
4	Engine control unit	127
4.1	Engine control unit	127
4.2	Checking control unit voltage supply	127
4.3	Procedure after voltage supply open circuit	129
4.4	Replacing engine control unit	130
4.5	Coding engine control unit	131
4.6	Coding variants of engine control unit	132
4.7	Adapting engine control unit to throttle valve control part	133
4.8	Adapting engine control unit to electronic immobilizer	134
5	Checking additional signals	136
5.1	Checking additional signals	136
5.2	Checking speed signal	136
5.3	Checking signal from/to air conditioning system	137
5.4	Checking signal from brake light switch and brake pedal switch	138
5.5	Checking driving range signal	141
5.6	Checking rpm signal	142
5.7	Checking data bus	142
28	Ignition system	144
1	Servicing ignition system	144
1.1	Servicing ignition system	144
1.2	General notes on ignition system	144
1.3	Removing and installing parts of the ignition system	145
1.4	Safety precautions	147
1.5	Test data, spark plugs	148
1.6	Checking Hall sender	149
1.7	Checking ignition transformer	151
1.8	Checking knock sensor	154
1.9	Check misfiring recognition	156